

Triple Protection Parental Controls

By setting a LOCKS PIN and a PURCHASE PIN you can:

1. Restrict viewing of unwanted programming based on ratings, content or channel numbers.
2. Restrict adult titles from showing in the guide.
3. Restrict purchases of VOD or PPV to only viewers that enter the correct PIN.

It's easy! Follow the steps below.

Restrict Viewing: Locks Setup

1. Press MENU on your remote twice.
2. Select SETUP. You might need to arrow down to page 2 of menu to get there. Then press OK.
3. Select PARENTAL CONTROLS SETUP. Press OK.
4. Enter a 4 digit Locks PIN. Reenter the PIN to confirm.
5. This PIN will now be required to restrict viewing through the on screen guide. You can set locks using the categories by Movie Rating, TV Rating, TV Content, Channel and Title.



Please see reverse for more Triple Protection Parental Control Tips.



